


# ZY-HM-140



## SPARE PARTS FOR ZY-HM-140

Part	Description	Qty.	Part	Description	Qty.
1	screw st3.9x30	4	40	Flat washer 5	8
2	rear cover	1	41	gear box	1
3	adorn	1	42	pin4h8x8	1
4	screw st3.9x10	4	43	screw ST2.9X10	2
5	hot proof pad	2	44	Bearing 628/8	4
6	brush holder	2	45	speed control	1
7	carbon bush	2	46	third drive gear	1
8	carbon brush cover	2	47	third initiative gear	1
9	pover cord	1	48	second initiative gear	1
10	sheath	1	49	motor housing	1
11	press board	1	50	big gear	1
12	screw st3.9x12	6	51	circular15	1
13	capacitor	1	52	bearingHK1010	1
14	switch	1	53	Screw M5X22	1
15	waterproof pad	1	54	Screw ST3.9x14	13
16	stator	1	55	handle cover	1
17	bearing holder	1	56	wind cover	1
18	bearing 6000	1	57	circular 17	1
19	screw st4.8x70	2	58	circular 35	1
20	rotor	1	59	circular 10	1
21	wind guide	1	60	bearing6003	1
22	screw stM4X6	3	61	first initiative gear	1
23	bearing 6001	1	62	second drive gear	1
24	intermediate cap	1	63	spindle	1
25	oil washer	1			
26	oil corduray	1			
27	oil cover	1			
28	washer 3 flat	4			
29	spring washer 3	4			
30	screw M3X10	4			
31	Screw M4x10	1			
32	speed shift knob	1			
33	spring	2			
34	ball 4	2			
35	circlip 28	1			
36	speed shift pole	1			
37	oil cover 21x26x5	1			
38	Screw M5X30	4			
39	spring washer 5	8			